

# Command:RELOCK (RL)

<b>Shortcut</b>	RL
<b>Format</b>	RL
<b>Firmware Module Required</b>	CRIFF or AF-DUAL

Turns on the CRIFF laser and initiates a LOCK state using previously saved reference values. Same as LOCK for AF-DUAL systems.

## Reply

:A is returned upon receipt of the command.

[commands](#), [ms2000](#), [criff](#), [afdual](#)

From: <http://www.asiimaging.com/docs/> - **Applied Scientific Instrumentation**

Permanent link: <http://www.asiimaging.com/docs/commands/relock>

Last update: **2019/04/18 23:33**

